Guide Repair prices – updated 13/3/24

Check and adjust

Check for airtightness, regulation, ring key height without dismantling instrument

Service

Strip instrument, oil body for wooden instruments, replace pads, springs and touch/bumper corks as required, reassemble checking pad seating and regulation.

Pad costs are variable dependent on the instrument, so charges will be variable, although smaller pads may be included in the service cost.

In general, cleaning and polishing will be included, but if very tarnished an extra charge may be made.

Repad

As service but replace all pads.

Overhaul

Replace all pads, springs and tenon corks, then as for service.

CLARINET	Eb/Bb/A	Alto	Bass		
Check/adjust	25	30	30		
Service	55	70	80		
Repad	POA	POA	POA		Pad choice
Overhaul	POA	POA	POA		Pad choice
Tenon cork					£10-15
Pads fitted (each)					£8-10
FLUTE	Student	Open hole			
Check/adjust	25	40			
Service	55	80			
Repad	POA	POA			
Overhaul	POA	POA			
Tighten foot joint					£10
Replace head cork					£10
Pads fitted (each)					£8-10
SAXOPHONE	Sop/Alto	Tenor	Baritone		
Check/adjust	30/30	35	40		
Service	90/75	90	100		
Repad	POA	POA	POA		Pad choice
Overhaul	POA	POA	POA		
Crook cork					£10-15
Pads fitted (each)					£10-20
Pads fitted (each)					£10-20
DOUBLE	Oboe	Cor	Bassoon	Contra	£10-20
DOUBLE REEDS					£10-20
DOUBLE REEDS Check/adjust	30	35	40	POA	£10-20
DOUBLE REEDS Check/adjust Service	30 75/85	35 90	40	POA POA	
DOUBLE REEDS Check/adjust Service Repad	30 75/85 POA	35 90 POA	40 100 260	POA POA POA	£10-20 Pad choice
DOUBLE REEDS Check/adjust Service Repad Tenon cork	30 75/85	35 90 POA 7	40 100 260 10+	POA POA POA POA	
DOUBLE REEDS Check/adjust Service Repad	30 75/85 POA	35 90 POA	40 100 260	POA POA POA	